





**WARNINGS**

- Not suitable for children under 3 years due to small parts which may pose a choking hazard.
- Not suitable for food or hot item contact.
- Hardware contains small screws with sharp points.
- Adult assembly required. Keep unassembled parts & hardware away from children.
- The packaging is not part of the toy. To avoid danger of suffocation, keep packaging away from children and dispose of safely before assembling the toy.
- Adult supervision recommended.
- Indoor use only.
- Keep away from fire!
- Please retain this information for future reference.

Conforms to EU Toy Safety Standard (EN71) & The EU Toy Safety Directive (2009/48/EC).

**USE AND MAINTENANCE**

- Use on a stable level surface only.
- Do not sit, stand or climb on toy.
- Always secure with the wall strap provided.
- Please check assembly at regular intervals and periodically tighten hardware if necessary.
- If maintenance is not carried out, the product could cease to function properly.
- Wipe clean only.
- Oven Glove/Apron/Tea Towel - Follow wash care instructions on sew label.
- Please retain this information for future reference.

**BATTERY INFORMATION**

The hob requires 2x AA (1.5V) batteries (included). Phillips/cross head screwdriver (not included) required to install batteries. The battery compartment is located on the underside of the unit. Carefully undo the screw and lift the cover on the battery compartment to install/replace batteries.

The extractor fan requires 2x AAA (1.5V) batteries (included). Phillips/cross head screwdriver (not included) required to install batteries. The battery compartment is located on the underside of the unit. Carefully undo the screw and lift the cover on the battery compartment to install/replace batteries.

The microwave panel requires 2x AAA (1.5V) batteries (included). Phillips/cross head screwdriver (not included) required to install batteries. The battery compartment is located on the right hand side of the unit. Carefully undo the screw and lift the cover on the battery compartment to install/replace batteries.

This symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by taking it to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. Please contact your local authority for more information about where you can drop off your waste for recycling.

This symbol indicates that the batteries in this product must not be disposed of with your other household waste as they may contain substances that could be harmful to the environment or human health. The AAA & AA (1.5V) batteries in this product should only be disposed of at a designated collection point or recycling facility.

Batteries should only be installed & replaced by an adult. The battery compartment screws should be secured by an adult before giving the toy to a child. Insert batteries with correct polarity (see markings). Use only batteries of the same or equivalent type as recommended. Rechargeable batteries are only to be charged under direct adult supervision. Rechargeable batteries should be removed from the toy before being charged. Do not attempt to charge non-rechargeable batteries. Do not mix batteries of different types or new & used batteries together. Remove exhausted batteries from the toy or during long periods of non-use. Do not short-circuit battery terminals. Dispose of batteries safely. Batteries can be recycled only by taking to recycling professionals. Do not attempt to burn batteries. Use collection points for batteries where available. Please retain these instructions as they contain important information about the product.

**CUSTOMER SERVICES INFORMATION**

If you require further information or help with this product, please quote the PLU and contact us at:  
8th Wonder Ltd., Unit E, Sovereign Business Park, Kingscroft Court, Wigan, WN1 3AP. Tel. 01942 829811 Email: info@8thwonder.co.uk

Little Town® CV9 2SH, UK. W91VE40, IRE.